

# Roll Screen Roll Screen

**JR-8** Double Side Roll Up 85cm x 2m  
**JR-8A** Double Side Roll Up 75cm x 2m  
**JR-8B** Double Side Roll Up 62cm x 1.8m

Weight: 3.5 - 6kg



**JR-9E** Economy Roll Up 85cm x 2m  
**JR-9E/80** Economy Roll Up 80cm x 2m  
**JR-29E** Economy Roll Up 62cm x 1.7m

Weight: 3.5 - 5kg



**JR-9A** Easy Roll A 85cm x 2m  
**JR-9A/2** Easy Roll A 1m x 2m  
**JR-29A** Easy Roll A 1.2m x 2m  
 62cm x 1.7m

Weight: 3.5 - 4kg



**JR-31** Changeable Roll Up Silver 85cm x 2.15m

Weight: 7kg



**Assemble Instruction:**

**Step 1**



**Step 2**




**Step 3**



**Step 4**



**Step 5**



**Step 6**



**Step 7**



**Step 8**



**Step 9**



**Step 10**




**Step 11**



**SZ-10BK** Black Classic Roll Up 85cm x 2m  
1m x 2m  
1.2m x 2m

Weight: 5kg



JR-15 Roll Up Classical Black  
JR-15/120 Roll Up Classical Silver


85cm x 2.15m  
1.20m x 2.15m

Weight: 7 -10kg




**Assemble Instruction:**

1. Loosen Allen Screws and slide graphic into top piece  
(Allen Wrench is located underneath stand).  
Tighten screws - do not overtighten.




2. Turn stand upside down on table.  
Remove protective strip from adhesive and carefully  
attach bottom of graphic.



3. Holding the graphic, carefully remove the pin on side of  
stand. NOTE! THE ROLLER IS NOW ACTIVATED.

4. Carefully guide graphic into the stand.



**Changing the Banner Graphic**  
Remove the pin from underneath the banner stand. Pull the graphic out as far as possible and insert pin into the side of banner stand. The graphic may need to retract a couple of inches in order to insert pin. Once pin is in place the retracting mechanism is locked. Remove the graphic and follow steps 1-4 to install the new graphic.